Structured Electronic Design Amplifiers: Basic Function Design Approach

1. Find an operating mechanism that provides an available power gain > 1

- 1. Find an operating mechanism that provides an available power gain > 1
- 2. Study performance versus costs of basic solution

- 1. Find an operating mechanism that provides an available power gain > 1
- 2. Study performance versus costs of basic solution
- 3. Find means to affect performance parameters by design

- 1. Find an operating mechanism that provides an available power gain > 1
- 2. Study performance versus costs of basic solution
- 3. Find means to affect performance parameters by design
- 4. Apply error reduction techniques for improvement of performance-to-cost ratio

- 1. Find an operating mechanism that provides an available power gain > 1
- 2. Study performance versus costs of basic solution
- 3. Find means to affect performance parameters by design
- 4. Apply error reduction techniques for improvement of performance-to-cost ratio
- 5. Keep the design process managable through orthogonalization of performance aspects and design aspects.

- 1. Find an operating mechanism that provides an available power gain > 1
- 2. Study performance versus costs of basic solution
- 3. Find means to affect performance parameters by design
- 4. Apply error reduction techniques for improvement of performance-to-cost ratio
- 5. Keep the design process managable through orthogonalization of performance aspects and design aspects.



- 1. Find an operating mechanism that provides an available power gain > 1
- 2. Study performance versus costs of basic solution
- 3. Find means to affect performance parameters by design
- 4. Apply error reduction techniques for improvement of performance-to-cost ratio
- 5. Keep the design process managable through orthogonalization of performance aspects and design aspects.



BSc course:
Design of application-specific amplifiers with OpAmps

- 1. Find an operating mechanism that provides an available power gain > 1
- 2. Study performance versus costs of basic solution
- 3. Find means to affect performance parameters by design
- 4. Apply error reduction techniques for improvement of performance-to-cost ratio
- 5. Keep the design process managable through orthogonalization of performance aspects and design aspects.



BSc course:

Design of application-specific amplifiers with OpAmps

MSc course:

Transistor-level design of application-specific amplifiers

- 1. Find an operating mechanism that provides an available power gain > 1
- 2. Study performance versus costs of basic solution
- 3. Find means to affect performance parameters by design
- 4. Apply error reduction techniques for improvement of performance-to-cost ratio
- 5. Keep the design process managable through orthogonalization of performance aspects and design aspects.



BSc course:

Design of application-specific amplifiers with OpAmps

MSc course:

Transistor-level design of application-specific amplifiers

